

Device not found

USER MANUAL & INSTRUCTIONS

DRONAVIA UPDATER SOFTWARE 🤡



- 1 SOFTWARE INSTALLATION
- 2 SOFTWARE USE
- 3 SOFTWARE UNINSTALL
- 4 CONTACT US

Stonavia Updater Software



The 'Dronavia Updater' software is currently available exclusively for Windows. A MacOS version is currently under development and will be available shortly.



The 'Dronavia Updater' software is only compatible with Kronos M₃D parachute systems and SDK modules, Kronos M₄D and Kronos M₄.

INSTELLETION Dronavia Updater Software No device connected Newest version. Device not found serial number. Device not found Device version. Release no Release note:

INSTALLATION


Dronavia Updater software

To install the 'Dronavia Updater' software, please follow the instructions below in order:

Instructions


Download the .exe file for the "Dronavia Updater" software from the Dronavia website. To do this, go to the "Dronavia Updater" section from the website menu, then select the "Dronavia Updater" software.






www.dronavia.com

Install the 'Dronavia Updater' software by double-clicking on the software icon. Then click 'Yes' to authorise installation.







INSTALLATION

Dronavia Updater software

Click on "Next" to continue the installation, then click on 'Install' to begin the installation. Finally, click on 'Finish' to complete the programme installation.







The 'Dronavia Updater' software is installed.





To update your Kronos system, please follow the instructions below in order:

Instructions

1 Start the 'Dronavia Updater' software to begin updating your Kronos system.



Connect your Kronos system to a Windows computer using a USB cable.

Then click on 'Find Device' to detect your Kronos system from the 'Dronavia Updater' software.



Warning

If several devices are connected simultaneously via USB, the 'Dronavia Updater' software will connect to the device found first.

If the system connection is successful, the 'Find Device' button will change to 'Disconnect', and a 'Connected' indication below the button will appear. The system information will then be displayed.





Warning

If your system is not recognised by your computer, you will need to reverse the direction in which the USB-C cable is connected.

If the system fails to connect, the 'Not Connected' indication below the 'Find Device' button will remain in place.



Then click on 'Check Firmware' to check whether an update is available. If an update is available, 'Newest version' will indicate the new version and the 'Update firmware' button will become clickable.








Warning

If no update is available, a 'No Update Available' window will appear.




Advice

Click on 'Release note' to view the changes made by the update. A window will appear.



7 Then click on 'Update firmware' to update your Kronos system.







8 Your Kronos system has been updated.




Warning

Under no circumstances should the Kronos system be disconnected from the computer during the update. Any interruption could corrupt the system, requiring it to be returned to Dronavia for repair.

9

If you disconnect the system before the update is complete, a 'No Device Found' or 'Please do not disconnect' window will appear. This window may also appear if the system encounters an unknown problem.






Warning

If you disconnect your system during the update and the 'No Device Found' or 'Please do not disconnect' window opens, please follow the instructions on page 11.

In the event of a problem, please send us the 'Dronavia Updater' software logs for analysis. Click on 'Help' and then on 'Log File'. The file explorer will open automatically. Compress all the files in .ZIP format, then send them to Dronavia.



DEINTALLATION

Dronavia Updater software

If you wish to uninstall the 'Dronavia Updater' software, please follow the instructions below in order:

Click on 'Applications and Features' in Windows, then search for and select the 'Dronavia Updater' application. Then click on 'Uninstall'.

