




MADE IN FRANCE 

[Find devices](#)  
Not connected 

[Check firmware](#)

[Update firmware](#)

Newest version: No device connected

Serial number: Device not found

Device version: Device not found

Release note: [Release note](#)

Pages

WWW.DRONAVIA.COM | +33 (0) 354 400 078 | VERSION 1.0

# USER MANUAL & INSTRUCTIONS

DRONAVIA UPDATER SOFTWARE 

# SUMMARY

## Dronavia Updater Software

1 SOFTWARE  
INSTALLATION

2 SOFTWARE  
USE

3 SOFTWARE  
UNINSTALL

4 CONTACT US



The 'Dronavia Updater' software is currently available exclusively for Windows. A MacOS version is currently under development and will be available shortly.



The 'Dronavia Updater' software is only compatible with Kronos M3D parachute systems and SDK modules, Kronos M4D and Kronos M4.

# INSTALLATION

Dronavia Updater Software

[Check firmware](#) [Update firmware](#)

**Newest version:** No device connected

**Serial number:** Device not found

**Device version:** Device not found

**Release note:** [Release note](#)

[Find devices](#)  
Not connected

# INSTALLATION


## Dronavia Updater software

To install the 'Dronavia Updater' software, please follow the instructions below in order:

### Instructions

1


Download the .exe file for the "Dronavia Updater" software from the Dronavia website. To do this, go to the "Dronavia Updater" section from the website menu, then select the "Dronavia Updater" software.




[www.dronavia.com](http://www.dronavia.com)

2

Install the 'Dronavia Updater' software by double-clicking on the software icon. Then click 'Yes' to authorise installation.



2







# INSTALLATION

## Dronavia Updater software

3

Click on "Next" to continue the installation, then click on 'Install' to begin the installation. Finally, click on 'Finish' to complete the programme installation.



4

The 'Dronavia Updater' software is installed. ✓

# UPDATE

of the Kronos system




# UPDATE

of the Kronos system

To update your Kronos system, please follow the instructions below in order:

## Instructions

- 1 Start the 'Dronavia Updater' software to begin updating your Kronos system.




- 2 Connect your Kronos system to a Windows computer using a USB cable.

# UPDATE

of the Kronos system


- 3 Then click on 'Find Device' to detect your Kronos system from the 'Dronavia Updater' software.



## Warning

If several devices are connected simultaneously via USB, the 'Dronavia Updater' software will connect to the device found first.

- 4 If the system connection is successful, the 'Find Device' button will change to 'Disconnect', and a 'Connected' indication below the button will appear. The system information will then be displayed.



## Warning

If your system is not recognised by your computer, you will need to reverse the direction in which the USB-C cable is connected.

# UPDATE

of the Kronos system

5

If the system fails to connect, the 'Not Connected' indication below the 'Find Device' button will remain in place.



6

Then click on 'Check Firmware' to check whether an update is available. If an update is available, 'Newest version' will indicate the new version and the 'Update firmware' button will become clickable.




# UPDATE

of the Kronos system


## Warning

If no update is available, a 'No Update Available' window will appear.



## Advice

Click on 'Release note' to view the changes made by the update. A window will appear.





# UPDATE

of the Kronos system

7

Then click on 'Update firmware' to update your Kronos system.



8

Your Kronos system has been updated. ✓

# UPDATE


of the Kronos system

## Warning

Under no circumstances should the Kronos system be disconnected from the computer during the update. Any interruption could corrupt the system, requiring it to be returned to Dronavia for repair.

9

If you disconnect the system before the update is complete, a 'No Device Found' or 'Please do not disconnect' window will appear. This window may also appear if the system encounters an unknown problem.



## Warning



If you disconnect your system during the update and the 'No Device Found' or 'Please do not disconnect' window opens, please follow the instructions on page 11.

# UPDATE

of the Kronos system

10

In the event of a problem, please send us the 'Dronavia Updater' software logs for analysis. Click on 'Help' and then on 'Log File'. The file explorer will open automatically. Compress all the files in .ZIP format, then send them to Dronavia.







# DEINSTALLATION

## Dronavia Updater software

If you wish to uninstall the 'Dronavia Updater' software, please follow the instructions below in order:

1

Click on 'Applications and Features' in Windows, then search for and select the 'Dronavia Updater' application. Then click on 'Uninstall'.



# CONTACT US



+33 3 54 40 00 78



support.updater@dronavia.com



www.dronavia.com



| Dronavia Channel

